



Franco Raggi, 1999



CODE	VOLTAGE	BULB	DIMENSIONS IN CM
3300 Flûte	120V	1x250W E26 type T	A: 27 - B: 192
3300/1 Magnum	120V	1x300W T3/L (HA)	A: 32 - B: 210

## CAUTION! IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other one) in order to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension card, unless the plug can be fully inserted. Do not alter the plug.

## CLEANING

Use only damp cloth with mild soap. Do not use alcohol or solvent. Keep these instructions for future reference.

## WARNING

Disconnect current prior to any assembling or repair. If not familiar with electrical connections, contact a qualified electrician. Keep these instructions for future reference.




Before any operation on the fixture, please disconnect the power supply.




In case of damage to the feeding cable, please contact a FontanaArte dealer or qualified personnel for replacement.


FontanaArte reserves the right to introduce all changes required for the improvement of the present product at any time and without prior notice.




After separating screw (1) from stem (2) by means of a screwdriver, assemble base (3) and bottom (4) and fix them to the stem by means of the screw and of gasket (5).



Position reflector (6) on rod (7) and, in order to fix it to the fixture, insert the three spacers (8) into the holes on diffuser (9) and screw them in the reflector holes.



Insert bulb (10) in the proper lamp holder (11).



To switch on the lamp and adjust light intensity use proper dimmer (13).